

Automatic Concrete Compression Machine

AC-250, AC-325, AC-450



AC-250



AC-325



AC-450

The Automatic Concrete Compression Machine frames are manufactured from structural steel angles welded to the top and bottom crossheads or main frame of a solid steel plate.

The AC-250 has the hydraulic cylinder assembly mounted to the top crosshead, with force being applied downward. This design eliminates foreign material build-up around the piston-cylinder area.

The AC-325 and AC-450 have the hydraulic cylinder assembly mounted to the bottom main frame of the compression machine and force is applied upwards. A metal shroud helps to protect the piston-cylinder area from concrete fragments and debris.

Please read through the entire manual to fully understand the operations of the Gilson Automatic Concrete Compression Machines.

Automatic Concrete Compression Machines

AC-250, AC-325, AC-450

CONTENTS

Introduction	1
Safety Warning	3
Machine Specifications	4
1.0 Receiving	5
1.1 Inspection.....	5
1.2 Uncrating.....	5
1.3 Initial Cleaning	5
1.4 Daily Cleaning.....	5
2.0 Installation	5
2.1 Machine Location.....	5
2.2 HMI (Touchscreen Interface) Installation	6
2.3 Connections and Setup.....	6
2.4 Installation of Accessories.....	7
3.0 Hydraulic System Setup	7
3.1 Bleeding Air from the System.....	7
3.2 Checking and Maintaining the Fluid Level	7
4.0 Operation	8
4.1 Calibration	8
4.2 Safety	9
5.0 Quick Test Guide	9
6.0 HMI (Touchscreen Interface) and Control System Operation	9
6.1 Main Test/Run Screen	9
6.2 HMI (Touchscreen Interface) Buttons	10
6.3 Display Fields	11
6.4 Specimen Information	12
6.5 Correction Factor	12
6.6 Break Type.....	13
6.7 Data Logging.....	13
6.8 Printing	13
7.0 Optional Machine Configurations	13
7.1 Modulus of Elasticity (MOE), or MOE and Poisson's Ratio	14
8.0 Maintenance	14
8.1 Checking and Maintaining the Fluid Level	14
8.2 Filling the Reservoir with Hydraulic Fluid	14
8.3 Bleeding Air from the System.....	15
8.4 Draining and Cleaning the Variable Frequency Drive (VFD) System	15
8.5 Replacement Parts	15
9.0 Verification and Calibration	15
10.0 Accessories and Replacement Parts	16
11.0 Technical Support	16

SAFETY INSTRUCTIONS

Please read these instructions thoroughly to familiarize yourself with the operation of the Automatic Concrete Compression Machine before attempting to run it.

The buyer is responsible for ensuring that users are properly trained, that they are aware of all of the information and instructions in this document, and that they are aware of the potential risks of operating the machine. The manufacturer will not be responsible for any damage to people and/or property caused by noncompliance with any instructions in this manual.

NOTE: These instructions are intended only as a guide for general operation of this device and should not be used in place of test protocol. Refer to current ASTM, AASHTO, and/or BS specifications for complete and detailed test procedures.

Always ensure the motor and other electrical components are properly configured for your intended use and available power source. Machines operate on either 110V,60Hz or 230V,50Hz.

Always use a properly-wired, three-pronged plug, or otherwise ground the machine. Make sure the cord is located where no one will trip or get tangled in it.

Always check electrical wiring for loose connections and for pinched or frayed wiring.

Always disconnect and lock out power supply when the machine is not in use, especially before performing maintenance and repairs.

- ▲ **WARNING:** This machine operates on an electric current. Improper operation could result in electric shock, electrocution, or an explosion! Motors are NOT explosion-proof!
- ▲ **WARNING:** Do not wear loose clothing that might be caught in the machine and keep all body parts away from moving parts of the machine. ALWAYS wear safety glasses, hearing protection, and other personal protective equipment while operating, maintaining, or repairing this machine.
- ▲ **WARNING:** DO NOT operate the machine without having all guards and covers in place.
- ▲ **WARNING:** DO NOT perform tasks on the machine other than those for which it was designed. Only use the machine in the manner for which it was intended, as described in this instruction manual.



NOTE: This machine has been operationally tested and calibrated at the factory. In order to fully comply with the requirements stated in ASTM C39, the Compression Machine should be calibrated again "on original installation or immediately after relocation." Gilson does not provide calibration services directly, but can provide a list of calibrators in your area. Contact our Technical Department at **800.444.1508** or **techsupport@gilsonco.com**.



Automatic Concrete Compression Machine AC-250, AC-325, AC-450

Automatic Concrete Compression Machine Specifications			
	AC-250	AC-325	AC-450
Load Capacity Range	2,500–250,000lbf	3,250–325,000lbf	4,500–450,000lbf
Vertical Opening	19.625in (498.48mm)	19.25in (488.95mm)	19.125in (487.775mm)
Horizontal Opening	9.25in (234.95mm)	9.5in (241.3mm)	9.5in (241.3mm)
Ram Diameter	6in (152.4mm)	6.75in (171.45mm)	8.5in (215.9mm)
Piston Stroke	2.5in (63.5mm)	2.5in (63.5mm)	2.5in (63.5mm)
Platen Hardness	60HRC	60HRC	60HRC
Lower Platen Dimension	6.5in (165.1mm) dia.	6.5in (165.1mm) dia.	10.5in (266.7mm) dia.
Upper Platen Dimension	6.5in (165.1mm) dia.	6.5in (165.1mm) dia.	6.5in (165.1mm) dia.
Fluid Reservoir Capacity	2 gallons (3.78L)	2 gallons (3.78L)	2 gallons (3.78L)
Overall Width	30in (762mm)	33in (838.2mm)	34in (863.6mm)
Overall Depth	17in (431.8mm)	17in (431.8mm)	24in (609.6mm)
Overall Height	58in (1,473.2mm)	58in (1,473.2mm)	60in (1,524mm)
Unit Weight	570lb (258.55kg)	720lb (326.59kg)	1,480lb (671.32kg)

1.0 RECEIVING

1.1 Inspection

Items are shipped in new condition and packed to withstand normal shipping risks. The Purchaser is responsible for checking all packages for damage or loss before accepting any shipment.

1.2 Uncrating

To properly uncrate your new testing machine:

- Remove metal straps around the crate/box with suitable cutters (shears) if banded.
- Remove the top of the box/crate.
- Remove wooden braces on the top and sides of the machine if braced.
- If crated, remove the sides of the crate. If boxed, remove the entire box.
- If accessories are included, unband/unbrace and remove accessories.
- Cut all remaining bands and remove all wooden braces on the pallet.
- Remove the machine from the pallet.
- Locate the packing list and refer to it to verify that all parts and units are present.

1.3 Initial Cleaning

To protect your new compression machine during shipping and through extended periods of exposure to the elements, a rust-preventative has been applied to the external surfaces of the machine. The rust inhibitor can be removed after positioning/installing your machine and before making the hydraulic connections.

- Please use rubber gloves while using the solvent. Dampen a clean, dry cloth with a suitable safety solvent, such as CRC Quick Clean or something similar.

NOTE: Do not soak the cloth or rub painted surfaces vigorously, as the solvent may attack the paint.

- Gently wipe the surfaces until tackiness is gone, then gently wipe with a dry cloth.

1.4 Daily Cleaning

To reduce particle contamination after testing, a dry wipe down should be done. Solvent need not be used unless an accumulation of particles is present and is otherwise hard to remove.

2.0 INSTALLATION

2.1 Machine Location

It is recommended that the machine be placed in an area where the atmosphere is free from acidic or contaminating fumes, which could accelerate the corrosion of machined surfaces or electrical contacts.

The machine should be placed in a temperature-controlled indoor environment where humidity or condensation is within the following limits:

- Temperature = 41°–104°F (5°–40°C)
- Relative Humidity= 30–70%

All machines should be accurately leveled and secured to the floor with anchor bolts for proper operation. This is especially important when testing high-strength concrete or utilizing pad caps. 1/2in diameter anchor bolts are recommended.

The machine should be positioned to allow sufficient space at the side and rear for calibration or servicing working space.

A dedicated electric outlet is recommended to help ensure that proper electricity is provided to the unit. Please check stamped identification plate for voltage and current requirements.

2.2 HMI (Touchscreen Interface) Installation

The HMI system is a touchscreen interface. It is packed separately and will need to be mounted to the Concrete Compression Machine.

- Remove the HMI (Touchscreen Interface) from its custom packaging and save it in the event it needs to be shipped again.
- Remove the screws, washers, and lock washers from the back of the interface and set them aside.
- Line up the HMI with the mounting bracket. There are two sets of four screw holes on the mounting bracket. The inner set of holes are utilized for mounting.
- Put one screw in to hold the touchscreen. Finger tighten this screw. Once the one screw is holding the HMI, align and finger tighten the remaining three screws (see Fig. 2a).
- Once all the screws are in place, tighten all screws. Care should be exercised not to overtighten (see Fig. 2b). (Fig. 2b only shows one screw attaching the HMI to the bracket. This image is for informational purpose only. When completing the installation of the touchscreen, four screws must be used.)
- Connect the power plug, round load signal cable, and Variable Frequency Drive (VFD) cable DB9 connector to their respective ports on the interface. Tighten the screws on the DB9 with a screwdriver so they are snug, but do not overtighten (see Fig. 2c).
- If your machine has any factory-installed options, such as MOE, there may be one or more additional USB connections. You may plug these connections into any of the available USB ports on the interface **EXCEPT** the blue port. The blue USB port is not available for machine connections and should only be used with an external USB device, such as a mouse, keyboard, or thumb drive.



Fig. 2a: Tighten screws with fingers



Fig. 2b: Tighten screws—do not overtighten

2.3 Connections and Setup

The Automatic Compression machines have one hydraulic connection and an over-travel limit protection switch pre-installed at the factory.

Other electronic devices, if applicable (i.e., LVDTs, position sensors, etc.), can be connected to available ports on the touchscreen interface.

Once all connections have been made, check the fluid level of the hydraulic reservoir. Machines are shipped with hydraulic fluid but add additional fluid to the reservoir if necessary. Fluid type is the readily available Dexron III or VI ATF, and the desired fluid level is 2in below the top of the reservoir with the piston fully retracted.

Check the stamped metal ID nameplate for voltage requirements, and connect the power cord of the machine to a standard wall plug.




Fig. 2c: Cable connections

NOTE: GFCI protected outlets should not be used. Nuisance tripping may occur due to the high-frequency switching of the VFD drive.

2.4 Installation of Accessories

Spherically-seated breaking heads and other top-mounted platens are held in place by a locking stem secured by a hex (Allen) head set screw. For AC-325 and AC-450 series machines, the set screw is installed in the front of the upper crosshead.

For the AC-250 series, the set screw is partially obscured when the loading piston is in the home position. To access the set screw, advance the piston about 1in and place the hydraulic control in the hold position.

Lift the accessory into position, inserting the holding stem firmly into the hole centered inside the frame. Then, tighten the set screw against the holding stem, locking the accessory in place. There should not be any force on the holding stem or set screw during testing. The force should be between the frame and blue seat of the testing accessory.

Note regarding Unbonded Capping: The sudden release of energy (when the specimen breaks) associated with rubber pad caps can greatly reduce the life of hydraulic and mechanical components. Pad caps are not recommended for prolonged testing beyond 60% of the machine's maximum capacity.

3.0 HYDRAULIC SYSTEM SETUP

Keeping the unit clean and the fluid free of dirt will increase the life of the pump, valve(s), and other hydraulic components. The fluid reservoir is filled prior to shipment with Dexron III Automatic Transmission Fluid (ATF). Fluid capacity is approximately 2 gallons, and fluid level should be approximately 2in from the top of the reservoir. See Section 8.0 if additional fluid needs to be added.

Testing accessories should be cleaned as needed. Spherical discs and seats should be disassembled, cleaned, and lubricated periodically with a light lubricant such as Dexron III ATF or spray lubricants. Do not use heavy lubricants such as grease, as dust and debris will collect in it and prevent the unit from rotating properly.

The reservoir should be drained and replenished with clean fluid at least once a year. The frequency of the fluid change will depend greatly on the general working conditions, hours of use, and the overall cleanliness and care given to the system.

3.1 Bleeding Air from the System

Upon initial startup, air can accumulate within the hydraulic system. The trapped air can cause the system to advance slowly or to surge and make the motor become noisy. To remove the trapped air:

- With fluid in the unit and the machine ready to operate under zero load, advance the piston about 2in of travel and then retract to the starting position. This should be repeated several times to work the air out of the system. If this does not remove all trapped air, continue to the next step.
- With fluid in the unit and the machine ready to operate under zero load, loosen a couple of turns, but do not remove, a hose fitting that is situated higher than the rest of the hose fittings in the system. Run the pump until a steady flow of fluid, free of air bubbles, is observed. Retighten the fitting.

3.2 Checking and Maintaining the Fluid Level

NOTE: The following operations should be performed with the power off and the piston retracted to effectively determine fluid level.

- After locating the pump and motor assembly, find the plug on the top of the reservoir cover plate.
- Check the fluid level in the reservoir by removing the fill plug and inserting the dipstick in the reservoir. The system is full when the fluid level measures 2in below the top of the tank when fully retracted. Overfilling may cause performance issues, leaking, and/or damage to the pump, motor, or valve(s).
- When it is necessary to add fluid to the reservoir, remove the cap and fill it to the proper level with Dexron III or VI ATF. The reservoir capacity is approximately 2 gallons.

4.0 OPERATION

Two major components make up the control system of this machine: the HMI (Touchscreen Interface) and the Variable Frequency Drive (VFD). The HMI allows for intuitive setup and use of the machine and the ability to view, analyze, and export test data. The VFD controls the motor speed, allowing very efficient use of hydraulic power.

▶ STARTUP

When the machine is plugged in, the power is supplied to many components. If the machine will be off for an extended period of time (a few weeks or more), it is recommended to unplug the machine.

The HMI (Touchscreen Interface) interface has a power button in the bottom left corner that turns it on or off. Once power is applied, a booting sequence starts and will last between 30 seconds and 2 minutes (see Fig. 4a).

When the booting is complete, the interface will finish by loading the automatic software package.

To turn the HMI off, momentarily push the power switch. This will initiate the operating system to shut down and prevent data loss or file corruption. Once the shutdown process has been completed, the PWR LED will extinguish, and line power can be disconnected. The system is designed to let power remain on the other components. If the system will be off for an extended period of time, it is acceptable to unplug the machine after the above shutdown procedure.



This device has been developed according to and complies with Windows Embedded, CE, FCC and RoHS standards and has been specified and programmed by the manufacturer. It is intended for use exclusively as a machine controller/display, and includes special provisions for manufacturer support access. Other use or modification of this equipment, including but not limited to: modification or removal of existing software, installation of additional software, or any use of this device other than for its intended purpose is prohibited. Violation of such prohibitions may result in unsafe machine operating conditions. Further, such violation renders the factory warranty null and void.

This touchscreen panel is factory configured for a particular machine frame. Do not transfer this panel to another frame without contacting the manufacturer. Failure to do so may compromise calibration accuracy and may result in unsafe machine operation. Not all panels are compatible with all frames. Transfer or reconfiguration of any touchscreen panel must only be done through consultation with the manufacturer.

Gilson HMI
Version 2.02

OK

Fig. 4a: Gilson HMI startup and information screens

▶ EMERGENCY STOP (E-STOP)

This button is a safety feature of the machine. If something unexpected happens while the machine is running, the “E-Stop” button can be pressed. Pressing this button removes all output power from the system. This means that the hydraulic pump motor will stop, and all controls and solenoids will return to their default positions. This button should be used in emergency situations to terminate hydraulic power to the machine. The button “locks” after being pressed and must be twisted to reset. Tripping the E-Stop is recommended during routine maintenance or service of the system, such as changing hydraulic fluid.

After the emergency condition has been addressed, the “E-Stop” button can be reset. The diagnostics screen will report when the E-Stop is activated by turning red. It may be necessary to press the “Reset Drive” button on the diagnostics screen to resume testing after an E-Stop condition.



4.1 Calibration

ASTM C39 requires concrete compression testing machines to be calibrated and verified annually in accordance with the most current revision of ASTM E4.

All safety devices and accuracy adjustments are preset during the calibration to give maximum performance and safe operation.

Each machine is fully serviced and calibrated at the factory. However, ASTM C39 requires that machines be calibrated after final installation or relocation.

Contact Gilson Technical Support at: 800.444.1508 or techsupport@gilsonco.com for assistance in finding an independent calibrator in your area.

4.2 Safety

- The hydraulic power unit utilizes an adjustable high-pressure relief valve, which protects the testing machine from becoming overloaded. This is factory preset and typically does not require any adjustment in the field.
- Fragment guards with heavy-duty latches and hinges are mounted to both the front and rear of the compression frame. Fragment guards incorporate Lexan® inserts for complete operator protection from flying debris when testing explosive, high-strength specimens. Lexan® also permits clear viewing of the test in process.
- Piston over-travel limit switches come standard on all Gilson Automatic Concrete Compression Machines. These switches prevent travel of the piston beyond the 2.5in stroke limit of the testing machine.

5.0 QUICK TEST GUIDE

- ➔ Always be aware of the “E-Stop” button location prior to operating the automatic machine. This is a red button, clearly marked on the machine’s console. If, at any time, you need to stop the system due to unsafe conditions, press the “E-Stop” button.
- ➔ Turn on the power to the machine and wait for the system to power up (if not already running).
- ➔ Check specimen/test type in the upper right corner, change to the desired specimen if needed. Make sure to check the specimen dimensions and set the ramp rate, break %, and preload.
- ➔ Load specimen in the machine according to applicable standards.
- ➔ Hold the “Jog Advance” button to advance the system for specimen centering/block seating procedures. Jog until there is a small gap between the platen and the specimen.
- ➔ Press the “Tare Load” button and perform centering block seating procedures per applicable standards.
- ➔ Hold the “Jog Advance” button to apply between 1–10% of the anticipated load on the specimen. Release the “Jog Advance” button and perform perpendicularity/alignment checks per applicable standards.
- ➔ Press the “Start Test” button if satisfied with the alignment and perpendicularity checks. If not satisfied, press the “Retract” button and repeat the previous step.
- ➔ The machine will rapidly advance to the preload amount, then switch to the preset ramp rate for the remainder of the test. The machine will stop and retract when a drop in load according to the break % is reached.
- ➔ If "Ask for Break Type" is selected, a break type can be chosen and included with the report (see Fig. 6d).
- ➔ Record the load at break, or stress at break as desired, or simply move on to the next test if the data logged results are used.
- ➔ Clean out the debris from the broken specimen and repeat the procedure from “load specimen in the machine according to applicable standards” if the specimen is the same size and type. If the specimen is a different size and/or type, repeat the procedure from “check specimen/test type,” and reselect before proceeding.

6.0 HMI (TOUCHSCREEN INTERFACE) AND CONTROL SYSTEM OPERATION

The HMI (Touchscreen Interface) is a powerful device that enables the setup of testing protocol, real-time display of test data, and post-test data transfer. The operator can navigate options for: Test Run, Test Setup, Machine Setup, Calibration, Reporting and Data Transfer, and Diagnostics. The interface provides a simultaneous display of force, stress, and rate of load, and displays a real-time graph of Load vs. Time or Stress vs. Strain.

The interface is equipped standard with Wi-Fi, USB inputs, and two LAN ports. The power switch is located in the lower corner. Always turn off the system by momentarily pushing the power switch. This will initiate the operating system to shut down and prevent data loss or file corruption. Once the shutdown process has completed, the PWR LED will extinguish, and line power can be disconnected. If being installed in an area with poor power reliability, the use of an uninterruptable power supply (UPS) is recommended.

6.1 Main Test/Run Screen

The “Main Test/Run” Screen is the base screen where testing is performed. It provides access to setup, calibration, diagnostics, and reporting.

6.2 HMI (Touchscreen Interface) Buttons

- **JOG ADVANCE:** This allows the user to jog advance the main ram. The ram only moves while the button is being pressed. Therefore, the button must be held to advance. Releasing the button will stop the advance and hold the ram in position. The button is green while being pressed and yellow when holding.
- **RETRACT:** This allows the user to retract (dump hydraulic pressure). Pressing the button will open the valve and dump all system pressure. It does not need to be held—a single press dumps the system.
- **START TEST:** When a test is ready, press this button to start the test. During preload, this button will be yellow. When a test is running, this button will be green.
- **STOP TEST:** During preload, a running test, or while paused, the “Stop Test” button can be pressed to stop the test. Pressing the button will stop the motor and open the dump valve to dump all system pressure.
- **TARE LOAD:** This allows the user to tare or zero the system load/stress.
- **SHOW GRAPH:** This shows a graph of the test when pressed. Button changes to “Hide Graph” when a graph is displayed. Press the button to close the graph in this state.
- **DIAGNOSTICS:** This allows the user to see the status of the “E-Stop” button, the VFD Drive, the pressure transducer, and the over-travel limit switch. The diagnostic button will show red if there is a problem or an activated item. Pressing the button brings up the screen below. A green indicator means the item is ready, while a red indicator means that the item is in a fault condition. You need to resolve any faults to achieve a green “System Ready” before you can proceed with testing.

The diagnostics screen for your system may have additional items to accommodate special features, such as MOE, secondary frame, or displacement.

- **USER INFO:** This allows the user to enter and store various names, companies, addresses, and other reporting information. Select the check box “Print Each Test” to print a report at the end of each test. This report is a detailed specimen report that includes a graph of Load vs. Time. For machines with other options, like MOE, additional graphs are included in the printed reports.




Fig. 6a: HMI (Touchscreen Interface) Buttons on Main Test /Run Screen




Fig. 6b: Machine Parameters (Machine Setup) Window

- **MACHINE SETUP:** This brings up a screen containing various units of measure and machine options (see Fig. 6b). A user can toggle on/off the checkbox for either the touchscreen or over-travel limit switch detection. It is strongly recommended to leave the over-travel limit switch detection on if the frame is equipped with the device.
- **VERIFY CALIBRATION:** This button allows access to the verification and calibration screens. Calibrating and verifying the machine allows for accuracy exceeding ASTM E4 requirements.
- **GENERATE REPORT/TRANSFER:** This button is used to reprint specimen reports, create summary reports, and transfer data files to an external USB flash drive.

6.3 Display Fields

- **LOAD:** This is the current live load measured at the machine's main ram. This is a calculated value based on the ram's hydraulic pressure and diameter. This value can be reset at any time, except when a test is running, by pressing the "Tare Load" button. Resetting the value allows for compensation for materials placed on the ram that do not exert force on the test specimen.
- **STRESS:** This is the current live stress measured at the machine's main ram. This is a calculated value based on the specimen's calculated load and surface area (or other methods per applicable ASTM or other standards). This value can be reset at any time, except when a test is running, by pressing the "Tare Load" button. Resetting the value allows for compensation for materials placed on the ram that do not exert force on the test specimen.
- **MAX LOAD:** This is the peak load encountered by the specimen since it was last reset. This value is reset at the beginning of every test.
- **MAX STRESS:** This is the peak stress encountered by the specimen since it was last reset. This value is reset at the beginning of every test.
- **RAMP RATE:** This displays the current ramp rate during a test.
- **THIS TEST:** The ID for the currently running or last completed test. This must be an integer on standard machines.
- **NEXT TEST:** This is the next test ID. It can be manually entered or auto-generated, as described below.
- **AUTO (CHECKBOX):** This is used to activate "Auto Test ID" mode. "Auto Test ID" mode allows the system to increment the test number by one for each test performed.



Fig. 6c: Display Fields on Main Test/Run Screen

6.4 Specimen Information

DROP-DOWN BOX - Select the specimen/test type to be run. This allows access to various specimen setup input parameters. Care should be taken when entering the dimensions, as specimen stress is calculated from this parameter. Care should also be taken when entering the following three important setup parameters:

- **BREAK:** Percentage threshold of the peak load used to detect a specimen break. For example, if the break % is set at 70% and the system maximum load is 100,000lb, a drop to 70,000lb or less would trigger break detection.

Care must be exercised if this setting is too high or too low. For example, if 95% was selected, the system may stop the test when a chip breaks off a corner. Full breaking stress may never be reached. Alternatively, if the percentage is too low, the system may never detect breakage, thus not stopping and retracting at the end of a test. A break % from 50% to 70% is recommended for most applications.

- **RAMP RATE:** Ramp rate desired. This value should be set based on testing standards.
- **PRELOAD:** Load threshold in which to perform rapid advance before controlling at the desired ramp rate. This value is the load before data collection begins. During preload, no break detection is applied. It is important to select a preload value that is high enough, so that break detection is not activated prematurely. In most applications, preload should not be set lower than 1% of a testing machine's capacity.

NOTE: ASTM C39 allows a fast advance up to 50% of the anticipated break strength before controlling at 35psi/sec.

6.5 Correction Factor

Per ASTM C39, only used for specimens that are not the standard 2:1 length to diameter ratio. When activated, the correction factor is applied to displayed values. A value of 1 should be used when diameter vs. length does not require applying a correction factor.

6.6 Break Type

Used to store the break type according to ASTM C39. When the checkbox "Ask for Break Type?" is selected, the system will prompt the user to choose the break type at the end of each test (see Fig. 6d).




Fig. 6d: Break Type selection window

6.7 Data Logging

Standard functionality includes data collection for printing and transfer.

The HMI also collects data from optional extensometer and compressometer displacement transducers. This data is captured with the same timestamp as the load data.

Press the “Generate Report/Transfer” button to manage logged data. Two data sets are stored on the machine. The summary data has information about the test performed, like peak break info, the test ID, and basic specimen information. The second data set is the test data and contains the Force vs. Time information for the complete test(s).

An external USB drive must be attached to the touchscreen to retrieve summary data, test data, or summary reports.

To generate a summary report, press the “Create Summary Report” button and then select one or more stored summary data files for your report. Press the “Generate Report/Transfer” button to generate the report.

To move either summary data or test data, select the “Move Summary Data” or “Move Test Data” button. Select the desired data files and then the desired location.

Select “Reprint a Previous Test Report” and then select the proper test ID to reprint a test report.

6.8 Printing

The system can be configured to print every test report. Most printers will be automatically set up by the operating system when connected.

Printer margins and the “Print Each Test” checkbox are found on the “User Info” tab. Select the checkbox to print each test.

7.0 OPTIONAL MACHINE CONFIGURATIONS

Optional machine configurations are available for Gilson Automatic Concrete Compression Machines. Options include Dual Frame machines, Dual Range machines, and Ram Displacement Measurement (for speed control).

- Dual Frame machines have a two-step process to change the frame selected. The operator must move the AB valve to the opposite position and press the button on the main screen for the primary frame or secondary frame.
- Dual Range machines allow selection of either a low or high range by pressing the button on the main screen.
- Ram Displacement Measurement Machines with the Displacement option can measure the movement of the ram. This gives a user the ability to select a speed at which a test occurs rather than just a loading or stress rate.

7.1 Modulus of Elasticity (MOE), or MOE and Poisson's Ratio

Modulus of Elasticity (MOE) testing can be selected from the specimen type drop-down menu on the main screen if optional equipment was factory-installed on the machine. Before you can start a MOE test, you must break a companion specimen in standard compression mode to get the strength of the specimens. This strength is then entered in the "Comp. Brk." field. Once a nonzero value is entered, the operator can proceed with setup and testing. Again, the "Run" and "Jog" buttons will be disabled until the companion break strength is entered.

The remaining parameters to setup are:

- **DIAM** = specimen diameter
- **Length** = specimen length
- **Weight** = specimen weight
- **Age** = specimen age
- **Ramp Rate** = rate of stress applied
- **Preload** = amount of load to apply before starting controlled ramp rate
- **Comp. Brk.** = break strength of the companion specimen (discussed above)
- **Cycles** = number of load/unload cycles to run
- **LVDT** = select desired LVDT (unit can store calibrations for six unique LVDTs)
- **Gauge Length** = gauge length per compressometer setup (via the "Setup" button)
- **Correction Factor** = $er/(er-eg)$, dimensional constant per ASTM C469 (via the "Setup" button)

During testing, you can either watch the normal display or select the "Show Graph" option to look at Load vs. Time or Strain vs. Time. While the test is applying load, the system will show a positive ramp rate. When the system is unloading, it will display a negative ramp rate.

Pressing the "Setup" button (next to LVDT) will allow the user to input the correction factor and gauge length.

If the machine is equipped with (optional) Poisson's ratio capability, you can perform Poisson's ratio testing by selecting the checkbox. Be sure the correct LVDT is selected in the drop-down list.

An example Load vs. Time graph is shown during the test by pressing the "Show Graph" button.

By pressing the "Stress vs. Strain" button, you can look at the Stress vs. Strain graph.

Once the test completes, the MOE value is displayed.

8.0 MAINTENANCE

8.1 Checking and Maintaining the Fluid Level

- After locating the pump and motor assembly, find the plug on the top of the reservoir cover plate.
- Check the fluid level in the reservoir by removing the fill plug and inserting the dipstick in the reservoir. The system is full when the fluid level measures 2in below the top of the reservoir when fully retracted. Overfilling may cause performance issues as well as leaking, and/or damage to the pump, motor, or valve(s).
- When it is necessary to add fluid to the reservoir, remove the cap and fill it to the proper level with Dexron III or VI ATF. The reservoir capacity is approximately 2 gallons.

8.2 Filling the Reservoir with Hydraulic Fluid

- On the back, top side of the reservoir, locate the plastic screw-in plug. This is the fill hole for hydraulic fluid. Clean the area around the plug to remove all dust and grit before removing the screw-in plug. Any foreign particles in the fluid could damage pump surfaces, resulting in loss of performance.
- Insert a clean funnel with a filter.
- Fill the reservoir with new Dexron III ATF to approximately 2in below the top plate of the reservoir. Do not overfill as this can cause poor performance, leaking, and possible damage to the system.
- Replace the plug.
- Test the system. Sometimes multiple starts and stops are needed to prime the pump following service.

8.3 Bleeding Air from the System

Upon initial startup, air can accumulate within the hydraulic system. The trapped air can cause the system to advance slowly or to surge and make the motor become noisy. To remove the trapped air:

- With fluid in the unit and the machine ready to operate under zero load, advance the piston about 2in of travel and then retract to the starting position. This should be repeated several times to work the air out of the system. If this does not remove all trapped air, continue to the next step.
- With fluid in the unit and the machine ready to operate under zero load, loosen a couple of turns, but do not remove, a hose fitting that is situated higher than the rest of the hose fittings in the system. Run the pump until a steady flow of fluid, free of air bubbles, is observed. Retighten the fitting.

8.4 Draining and Cleaning the Variable Frequency Drive (VFD) System

- Disconnect the power and ensure the piston is retracted.
- Thoroughly clean the pump exterior
- Disconnect the high-pressure line and set it in a clean bucket.
- Remove the solenoid from the valve cartridge by unthreading the cap and sliding it upward off the valve.
- If your system has a transducer attached to the high-pressure line, disconnect it by unscrewing the signal cable.
- With all attachments now disconnected, remove the four bolts holding the reservoir to the shelf.
- Remove the screws along the top plate of the reservoir.
- Lift off the motor, top plate, and pumps as one unit and carefully rest the unit on its side on clean rags to soak up excess hydraulic fluid.
- Check and clean the filter screen on the intake of the pump assembly. A soft brush can remove any build-up on the screen.
- Drain the fluid from the reservoir.
- Using a lint-free cloth, wipe out any remaining fluid and debris from the bottom of the tank.
- Once complete, partially fill the tank with approximately one gallon of clean fluid.
- Reconstruct the top assembly to the reservoir, changing the gasket if necessary.

8.5 Replacement Parts

When ordering parts, please refer to your testing machine's model and serial number. This information can be found on the metal information tag of the testing machine, typically affixed to the upper left side of the frame.

Contact Gilson Technical Support at: 800.444.1508, or techsupport@gilsonco.com for assistance in performing maintenance or identifying replacement parts for your Automatic Compression Machines.

9.0 VERIFICATION AND CALIBRATION

Before the machine can be used, it must be properly calibrated and verified. While machines are always factory calibrated, ASTM C39 requires the machine to be verified in accordance with ASTM E4 after it is installed in its final location. Verification is completed on the "Verify Calibration" screen. If necessary, calibration is performed by pressing the "Calibrate Machine" button on the verification screen. Please note the user must have the proper password to calibrate the machine.

Contact Gilson Technical Support at: 800.444.1508, or techsupport@gilsonco.com for assistance in finding an independent calibrator in your area.

10.0 ACCESSORIES AND REPLACEMENT PARTS

AC-250 AND AC-325 SERIES

- **ACA-122** 2x4in Cylinder Test Set for use with Bonded Caps
- **ACA-120** 2x4in Cylinder Test Set for use with Unbonded Caps
- **ACA-132** 3x6in Cylinder Test Set for use with Bonded Caps
- **ACA-130** 3x6in Cylinder Test Set for use with Unbonded Caps
- **ACA-142** 4x8in Cylinder Test Set for use with Bonded Caps
- **ACA-140** 4x8in Cylinder Test Set for use with Unbonded Caps
- **ACA-162** 6x12in Cylinder Test Set for use with Bonded Caps
- **ACA-160** 6x12in Cylinder Test Set for use with Unbonded Caps¹
- **ACA-200** Flexural Test Set
- **ACA-320** 2in Cube Test Set
- **ACA-360** 6in Cube Test Set
- **ACA-440** Tensile Splitting Set, 4x8in Cylinders
- **ACA-460** Tensile Splitting Set, 6x12in Cylinders
- **ACA-540** Compressometer, 4x8in Cylinders
- **ACA-560** Compressometer, 6x12in Cylinders
- **ACA-640** Compressometer/Extensometer, 4x8in Cylinders
- **ACA-660** Compressometer/Extensometer, 6x12in Cylinders
- **ACA-730** Grout Prism Test Set
- **ACA-820** Proppant Crush Testing Set
- **PRA-14** Proppant Crush Cell and Piston
- **MCA-44** Perpendicularity Verification Device for 4x8in Cylinders with 4in Spacers
- **MCA-44N** Perpendicularity Verification Device for 4x8in Cylinders without Spacers
- **MCA-46** Perpendicularity Verification Device for 6x12in Cylinders
- **MCA-41** 4x8in Gap Measurement Tool
- **MCA-42** 6x12in Gap Measurement Tool

¹Included with compression machine

AC-450 SERIES

- **ACA-123** 2x4in Cylinder Test Set for use with Bonded Caps
- **ACA-121** 2x4in Cylinder Test Set for use with Unbonded Caps
- **ACA-133** 3x6in Cylinder Test Set for use with Bonded Caps
- **ACA-131** 3x6in Cylinder Test Set for use with Unbonded Caps
- **ACA-143** 4x8in Cylinder Test Set for use with Bonded Caps
- **ACA-141** 4x8in Cylinder Test Set for use with Unbonded Caps
- **ACA-163** 6x12in Cylinder Test Set for use with Bonded Caps
- **ACA-161** 6x12in Cylinder Test Set for use with Unbonded Caps¹
- **ACA-200** Flexural Test Set
- **ACA-321** 2in Cube Test Set
- **ACA-362** 6in Cube Test Set
- **ACA-441** Tensile Splitting Set, 4x8in Cylinders
- **ACA-460** Tensile Splitting Set, 6x12in Cylinders
- **ACA-540** Compressometer, 4x8in Cylinders
- **ACA-560** Compressometer, 6x12in Cylinders
- **ACA-640** Compressometer/Extensometer, 4x8in Cylinders
- **ACA-660** Compressometer/Extensometer, 6x12in Cylinders
- **ACA-731** Grout Prism Test Set
- **ACA-821** Proppant Crush Testing Set
- **PRA-14** Proppant Crush Cell and Piston
- **MCA-44** Perpendicularity Verification Device for 4x8in Cylinders with 4in Spacers
- **MCA-44N** Perpendicularity Verification Device for 4x8in Cylinders without Spacers
- **MCA-46** Perpendicularity Verification Device for 6x12in Cylinders
- **MCA-41** 4x8in Gap Measurement Tool
- **MCA-42** 6x12in Gap Measurement Tool

11.0 TECHNICAL SUPPORT

Contact Gilson Technical Support for assistance with operation, maintenance, or repair of the Automatic Concrete Compression Machine.

- **Telephone:** 800-444-1508
- **Email:** techsupport@gilsonco.com
- **Web:** globalgilson.com