

Screen Tray Rack TSA-156

FEATURES

Part No.	Description	Quantity
1	Top	1
2	Left Side	1
3	Right Side	1
4	Back	1
5	Bar	1
	#10-24 x 0.375in Bolts	12
	#10-24 x 0.625in Bolts	2


ASSEMBLY

- Stand the Left Side (2) panel vertically on a flat surface with tray flanges facing inward. There should be a single threaded insert at the front bottom, and three inserts at the back.
- Attach the Back (4) panel by installing three #10-24 x 0.375in bolts¹ into the threaded inserts.
- Stand up the Right Side (3) panel with the tray flanges facing inward, and single threaded insert at the front bottom. Attach to the Back (4) panel, using three #10-24 x 0.375in bolts.
- Place the Top (1) on the tray rack with the flanges facing down. Secure with six #10-24 x 0.375in bolts.
- Attach the Bar (5) to the bottom front using two #10-24 x 0.625in bolts.
- Check for proper installation and alignment of components, and tighten all fasteners.

¹All bolts are Whiz Lock® brand serrated flange fasteners.



TSA-156



TSA-156 Parts Diagram

Rev: 02/2019