



# Marshall Compactors

Model	Manual	Automatic	Stationary	Rotating-Base	Blow-Counter	Number of Molds/ Hammers	Mold Size (in)
<a href="#">MS-1</a>	—	X	X	—	—	1	4
<a href="#">MS-2</a>	—	X	—	X	X	2	4
<a href="#">MS-3</a>	—	X	—	X	X	3	4
<a href="#">MS-5</a>	—	X	—	X	X	1	4 (standard) or 6
<a href="#">MS-6</a>	—	X	—	X	X	1	6 (standard) or 4
<a href="#">MS-10</a>	X	—	X	—	—	1	4