

SGA-11 Alternate Clamping System



INCLUDED ITEMS

- 3/8" Diameter Adjustment Rods, qty 2
- Threaded Adapters, qty 2
- Steel Tilt Knobs, qty 2
- Bottom Knobs, qty 2

INSTALLATION

- Remove existing clamp rods and knobs on your SGA-5R, along with the top plate.
- Install threaded adapters to the top of the SGA-5R base plate.
- Insert new adjustment rods into the adapters and thread into place.

- Next install the bottom plastic knobs onto the rods, with the larger side down.
- Place top plate onto the two threaded rods.
- Install the steel tilt knobs on each rod and move down to meet the top plate.

CLAMPING SYSTEM INSTRUCTIONS

Adjust the bottom knobs into position so the top plate will rest on the pycnometer. Then tilt and slide the top knob into place on top of the clamping plate. To tighten, straighten the knob and turn clockwise to engage threads. To loosen knob, tilt and slide up.